


Effective Mixing

Installation, Operation, Maintenance Manual



Edition 2015.01

This instruction Manual may only be used by the buyer or user. It can not be distributed, published, reproduced (partially or totally) or, in general, communicated to third parties without the express written permission of the seller. Any breach of these rules may be subject to legal action.

Index


General	3
Identification	4
Spare parts and repairs.	4
Warranty	5
Safety advices.....	6
Basic safety rules:.....	7
Reception, storage and carriage	9
Tank. Efforts and weights of mixer	11
Mounting and installation.....	13
Mounting of shafts	14
Propellers Fixation.....	17
Lubrication.....	22
Description:	22
Position of the venting plug, oil input plug and oil drain plug.....	25
Start-up.....	26
Motors.....	26
Variable-speed driver.....	28
Reducers.....	29
Sealing systems	30
Thermosiphon.....	31
Comissioning of mixer.....	32
Trouble-shooting	34
Maintenance	35
Motor	35
Reducer	35
Sealing systems	35
Thermosiphon:.....	36
Shafts and turbines	36

Technical data sheets and spare parts list	37
VHS3 SERIES.....	38
VHS3 Exploded view drawing.....	39
VHD3 SERIES.....	40
VHD3 Exploded view drawing.....	41
VPP3 SERIES	42
VPP3-VPH3 Exploded view drawing	43
VTA SERIES	44
VTA4 Exploded view drawing.....	45
VTS4-VTH4 SERIES.....	46
VTS4 Exploded view drawing.....	47
VPT3 SERIES	48
VPT3 Exploded view drawing	49
VPS3 SERIES.....	50
VPS3 Exploded view drawing.....	51
VFR3 SERIES	52
VFR3 Exploded View Drawing.....	53
VFT2 SERIES.....	54
VFT2 Exploded view drawing	55
L SERIES	56
L Exploded view drawing	57
HPS3 SERIES	58
HPS3 Exploded view drawing	59
Reducer section.....	60
Appendix.....	62
Tightening torque for screws	62
Deflectors.....	63
Declaration of conformity	64
ATEX Certificate.....	65
ISO 9001	66

General

- ✓ This technical manual contains the necessary instructions to install, start and maintain of FLUIDMIX® agitators and must be in hands of the personal in charge of these tasks.




- ✓ It is imperative to read this manual before the mounting, disassembling or start-up of mixers, in order to avoid risks of accidents and damages to persons, to machines and installations.
- ✓ In the repairs accomplished by the user himself / herself, use only original spare parts. Ask [FluidMix](#) for information about recommended spare parts and agitators section drawings.
- ✓ It is advisable that the user keeps in his stockroom spare parts recommended by [FluidMix](#) to be able to repair the machine as soon as possible.
- ✓ Instructions must be followed carefully in case of 'Ex' mixers for explosive atmospheres, preceded with  symbol (these instructions only refer to Ex certificate mixers).

Identification

Identification plate:

 	
AGITADOR/MIXER	<input type="text"/>
REFERENCIA/REFERENCE	<input type="text"/>
FECHA/DATE	<input type="text"/>
Nº	<input type="text"/>
Fabricado en España/Made in Spain Phone: +34 911 701 924	

- ✓ Each agitator has got a characteristic plate in stainless steel with the following information (except for small special models integrated in equipments):
- ✓ Agitator model
- ✓ Reference **FluidMix** (OW-xxxxx).
- ✓ Fabrication date
- ✓ Fabrication number
- ✓  'Ex' mark
- ✓ In case of spare parts request or information about our machines, and in order to avoid mistakes, you have to mention the data of the characteristics plate, specially **FluidMix** reference and the

fabrication number.

Spare parts and repairs.

➤ Spare parts:

- ✓ It is essential to use original spare parts for **FluidMix** mixers
- ✓ To avoid mistakes when asking for spare parts it is necessary to mention the data of the characteristics plate, specially **FluidMix** reference (OW-xxxxx) and the machine fabrication number.

➤ Repairs:

- ✓ **FluidMix** has got a repair service in our workshop. We will give you a quotation once the machine has been checked and before repairing it.
- ✓ In case of breakdown, please, contact **FluidMix** to try to solve the problem by phone. If this were not possible, it is necessary that you send us the machine, **always freight prepaid**, together with a note explaining the damage. Machines under guarantee are repaired and sent back as soon as possible and for those which are not under guarantee we give quotation and wait for its acceptance.
- ✓ If there are big machines which dismantling or transport invalidate the previous system, our technicians would move to the installation, subject to the acceptance of the written quotation.

Warranty

- **General:**
- ✓ **FluidMix** guarantees its supply during 12 months after the delivery against any defect of design, material or execution. This guarantee covers the substitution or repair by our charge and in our workshops of all faulty parts, being the buyer who must prove the mentioned defects. The substitution of one or several parts during the guarantee period does not extend this period.
- ✓ **FluidMix** guarantees only covers the supplied machine(s); no reclamation is admitted in case of breakdown for possible damages caused to the installation, to the product or to the quality of the production or for a decrease of it.
- **What the warranty do not cover:**
- ✓ Costs resulting from dismounting, assembly and transport operations.
- ✓ Damages caused by an incorrect installation.
- ✓ Deterioration due to negligence.
- ✓ Damages caused by maintenance defects.
- ✓ Parts submitted to wear.
- ✓ Working after modifying the service or exploitation conditions.
- ✓ Deterioration resulting from storage in unsuitable conditions.
- ✓ Installation of spare parts or accessories different from **FluidMix** supply.
- ✓ Dismounting by the user of subsets such as mechanical seal cartridges, reducers or motors **invalidates the warranty**.
- ✓ Wear in the shaft and propellers coating, rubber or plastic, because it is considered as normal.

Safety advices

Safety symbols:

Safety messages and warning labels must be strictly adhered to in order to prevent accidents, as well as personal and property damage. The content of the section and embedded safety messages as well as warning labels in the individual risk levels is as follows:

Dangers:



Danger



Warning: The machine can be damaged.



Danger of electric current.



Risk of being bruised by moving parts.



Floating load. Danger of carriage.



Danger of falling-down parts.



Danger of falling.



Danger of poisoning.



 Danger of explosive atmosphere.

Imperatives:



Documentation. Consult it unconditionally!



Safety helmet.



Carrying strap.



Respiratory mask.



Lifting machines.

Basic safety rules:

➤ Motor:

- ✓ Comply with current electrical regulations.



- ✓ The cable entry in the terminal box is made through a gland with characteristics appropriate to the installation. Once the connection is realized, mount terminal box cover with its corresponding gasket to prevent accidental contact with terminals.



- ✓ Always connect the motor housing to a ground.
- ✓ Motors must always operate with the fan cowl mounted in position; top grille must be free from obstructions to avoid excessive heating of the motor.

➤ Reducer:



- ✓ The agitator moving parts that are not inside of the tank should be covered with protections (grids, plates...) to prevent accidental contact. If due to the constructive characteristics of the equipment it's impossible to mount a protection "avoid inserting hands or any object through the existing access"

➤ **Mobile parts:**

- ✓ Protections shall only be removed for maintenance. Once carried out, refit all guards before restoring power.

➤ **Tank:**



- ✓ No work outside or inside of the tank can be made without making sure the disconnection of the power supply and clearly indicating at the point of disconnection, the works that are being carried out at the mixer area.



- ✓ All tanks, open or closed, require special security measures. It is essential that personnel of installation, commissioning and maintenance of the equipment are aware of such measures.



- ✓ A tank can be considered a "confined space", which implies a number of special risks, such as the lack of oxygen. Never enter a confined space unless you are fully trained and have proper safety equipment.



- ✓ In general, before entering a deposit it is required the necessary equipment to verify that it is a safe atmosphere as well as helmet protection, safety harnesses and lifting equipment.



- ✓ Open vessels equipped with an agitator must be provided with adequate protection to prevent the fall of objects or persons inside the tank, as well as accidental contact with moving parts. The user is responsible for adapting these protections.



- ✓ Before entering a deposit make sure that there are no noxious or explosive gases inside.



- ✓ For potentially explosive existing conditions, take all necessary measures to get make the work area safe, requiring special tools and work processes. If this is not possible, a risk analysis must be done.

Reception, storage and carriage

➤ Reception:

At reception of the material it is essential to check the following points:

- ✓ Check the transport delivery note with the material, number of packages, point of departure, etc...
- ✓ Specify in writing to the forwarder who delivers any fault observed in the external of the packing such as strokes, breakings, humidity, rips, etc. opening immediately the package with faults and verifying its content. In case of receiving damaged goods, immediately inform the forwarder and **FluidMix**. **In case of not doing like that, the eventual claims would be invalidated.**

➤ Storage:

- ✓ Store the device in its packing, in a dry place protected against strokes and dust, making sure previously that this packing is the suitable to support the environmental conditions in site. Any defective storage before and after the use under special environmental conditions (humidity, salinity, dust, vibrations, corrosion, etc.) restricts the conditions of the guarantee.
- ✓ Before starting an agitator that has been mounted but has not worked or has been stopped for a long time, check out that there are no leaks of lubricant and the sealing of the motor since, keeping the agitator out of work, especially if it is outdoors, can lead to damage or hardening of the joints leading to leaks of lubricant, or water entry in the motor.
- ✓ Shafts must be located on an even surface, with its corresponding protections or packings. Never use the agitator shaft as a lever or put weight on it.
- ✓ **In case of assemblies shaft-propeller(s) coated with plastic or rubber consider the previous precautions** since just the rub with the floor can cause an exposed metallic point by which the corrosion will start; remind that coating is usually fragile and it is easy to deteriorate if there is not a **very careful manipulation** during storage and assembly.

➤ Carriage:



- ✓ The agitators, depending on the model, they are too heavy to be stored or installed manually. Use a suitable transport.
- ✓ Take every precaution to lift the agitator. Always use the sling hooks when being transported by lifting system.



- ✓ Larger gearboxes have threaded holes for screw according to DIN 580 lifting lugs or Eyebolts. The bolts are not included in the supply.
- ✓ All the eyebolts must be tightened screwed.
- ✓ If you need auxiliary elements of lifting and transport suitable with sufficient capacity, as flat rising (EN 1492-1) and lashing or stowing (EN 12195-2) webbing slings should be used.



- ✓ The machines of transport and lifting should be ensured against slippage!



- ✓ Maximize all precautions possible to lift the agitator. Always use tight slings if you move the agitator with a crane or other lifting system. Lifting or transport with several assistants, two cables or slings must withstand the weight.


Tank. Efforts and weights of mixer

➤ General recommendations:

- ✓ Vessel which will incorporate the agitator must have the necessary design features to:
 - Avoid vibrations and oscillations of the vessel.
 - Avoid damages in the tank in case that shaft or propeller could loosen by accident or breakdown, even rotating at high speed, with the possibility of a leak of liquids, that may be toxic and/or corrosive.
 - FluidMix declines any responsibility for breakage of a deposit whose design must necessarily contemplate and take into account this possibility of accident.
- ✓ The mixers are designed for mounting on a standard flanges, DIN, ANSI, usually in a vertical position at the top of the tank, although there are other models that are mounted on the side of the tank in a horizontal position.
- ✓ For the fixation of the agitator in a concrete slab, we recommend, to do it with threaded rods.
- ✓ For the correct fitting of the agitator on the tank, it is essential to keep in mind the following points:
 - The mixer shaft is designed to run in a vertical position.
 - Check the horizontal alignment of the assembly drawing according to two perpendicular directions, rectifying the position through the use of cleats, in order not to force the counter flange fixing. Mount and secure with the pair of torque corresponding to the measurement of the screw. See "pairs of tightening" in Appendix.
 - Agitator turbine or propeller should not be directly affected by current flow. If by design of the reservoir conditions the current flow has direct impact on the shaft or turbine, screens baffle must be prepared.

➤ Efforts and weights of mixer

- ✓ During the operation of the agitator, due to turbulence and another series of complex hydrodynamic phenomena, each propeller produces a radial resulting perpendicular to the axis of the agitator and effort applied at its end. This effort multiplied by the length of the shaft gives the bending moment that should be considered for calculating the support structure. Due to the random nature of the forces and the rotation axis, the direction of these forces is constantly changing.
- ✓ For this reason is essential to respect the distances of blades Assembly to the support of the shaker plate, since the machine has been calculated with this hypothesis; placing mobile support plate distances greater than expected can cause serious mechanical faults that in no case would cover the guarantee of FluidMix.
- ✓ An axial flow Turbine generates an axial upward or downward effort depending on whether it is blowing or suctioning, respectively. If the axial stress is up will compensate in whole or in part the weight of the agitator, and may even exceed this weight. If the effort is falling will be added to the weight, what must be taken into account to calculate the corresponding
- ✓ Agitator support structure has been designed to withstand the forces mentioned above, and as a result, the forces are transmitted directly to the mounting bracket. **The support structure must be rigid enough to withstand the weight of the agitator and agitator reactions resulting from the axial stress, the moment torque and bending moment.**
- ✓ On request, FluidMix will facilitate static and dynamic efforts produced by the agitator so that manufacturer of the tank could calculate the appropriate structure support.



Mounting and installation

➤ General recommendations:



- ✓ Make sure that there is a sufficiently rigid support on top of the tank; the lack of rigidity of the support can cause vibrations and damage the agitator.

- ✓ For centered placement in cylindrical tank it is necessary to place three deflectors with an angle of 120° with the dimensions shown on the "DEFLECTORS" section. In case these deflectors don't exist it is necessary to place the agitator with its shaft in the middle of a radius of the tank.

- ✓ Fasten the flange to the structure using the specific screws and nuts (not included in the supply).
- ✓ The agitators, as a general rule, are shipped unassembled, or shaft or mobile, supplying motor reducer on one side and shaft and mobile(s) of the agitator on the other.
- ✓ Once mounted motor reducer according to the recommendations above, it must be mounted the shaft and mobile according to the instructions in the next section.



- ✓ In those agitators that have mounted sealing systems, follow the recommendations of the section "Sealing systems"



- ✓ In the case of several mobiles on the same axis, they have to be placed respecting the mounting positions provided in the project (see respective data sheets and supply).

- ✓ Fill completely the tank with water to do the first test.



- ✓ Connect the motor following the instructions indicated on "MOTORS" section and/or the specific instructions that can be supplied with the motor.

- ✓ Turn the agitator on verifying that the turning direction is the one indicated by the arrow drawn on the reducer for blowing position(*) and the opposite for sucking position; in case of opposite turning direction reverse two phases of the motor.




- ✓ It's not advisable to turn agitators during long time in empty tanks or with the propeller insufficiently submerged.
- ✓ No way the agitator shaft must be submitted to bumps or stresses for which it has not been calculated, for example, using it as a lever or to support weight.
- ✓ When the agitator is made of coated steel the propeller and the shaft and propeller is a single piece, be cautious when manipulating these pieces because coating is extremely fragile and can't be submitted to any bump or friction because it would immediately create a corrosion point, which would progressively lift the protecting coat and destroy the base material.

(*)To clarify the meaning of "sucking" or "blowing" propeller consult "PROPELLERS FIXATION" section.

Mounting of shafts

➤ Description:

The shaft's mixer assembly system will generally depend on if there is or not reducer gear, type of reducer and sealing system provided in each agitator (if existing).





- In VHD3 and VHS3 agitators, the motor are mounted directly and they have connecting elements between engine and shaft, such as sleeve or shield with guide bearing.
- Insert up to the limit the end of the agitator shaft in the corresponding housing of the bearing box (model VHD3) or the guided sleeve (model VHS3) tightening the allen screws through the existing drills at the side of the guided bearing box or sleeve.
- Be cautious to place the mechanized plan of in front of the subsection screw.
- Be sure to tighten all the screws Allen with the couple of tightening listed in "Appendix".
- **Never turn an agitator VHD3 or VHS3 in an empty tank or with the propeller insufficiently submerged. Running in these conditions would lead to damages to the shaft and to the guided bearing box or sleeve.**

In those agitators with mounted reducer gear, distinguish between those with solid output shaft and those with hollow shaft, adopting forms of assembly according to listed as follows:

Solid output shaft:


The assembly can be with:

- **Sleeve and allen screws:** Insert up to introduce the end of the shaft of the agitator in the corresponding housing of sleeve and tighten screws Allen set (see section "TIGHTEN PAIRS"). Be cautious to place the mechanized plan of in front of the fastening screw.
- **Coupling, screws, nuts and washers:** Locate the flange of the agitator shaft on the coupling with the screws included in the delivery (see the section "TIGHTEN PAIRS"), previously removing any trace of paint or varnish which has been able to get in the faces and paying special attention to the proper support of the coupling and flange faces.






Hollow shaft:

The assembly can be with:




- **Screw, washer and key:** Insert the shaft through the hole in the reducer to bump into the gear hollow shaft, then assembly the washer and tighten the fixing screw (see section "TIGHTEN PAIRS").
- Be sure to tighten all the allen screws with the couple of tightening listed in "Appendix".

- Screw, washer, circlip and key: Apply anti-corrosive paste to agitator shaft both, inside and outside of the hollow shaft of the gearbox




- Shrink disc:


The locking of the shaft to the moto-reducer is made by the shrink disc on top of the hollow shaft of the gearbox. Below are the steps to follow to carry out the shaft assembly:



- Thoroughly degrease the bore over the entire hollow shaft length to make sure that remainders of the anticorrosion agent will not be carried off into the area of the shrink disc when pushing on the agitator.
- Slightly loosen clamping screws one after the other, do not unscrew!
- Position shaft end of the agitator at the entrance of the hollow shaft of gearbox, and after align it correctly, insert the shaft to stop.
- Slightly tighten clamping screws manually.



- Tighten clamping screws one after the other in several passes, with rising torque, evenly until the indicated screw-tightening torque is reached at all screws.



- Several (in general more than 5) passes are necessary until the full tightening torque is reached at all screws! The shrink disc is mounted correctly and fixed when the faces of the outer ring and the inner ring are aligned



Hollow shaft bore [mm]	20	25	30	35	40	50	60	65	80	100
Torque [Nm]	12	30	30	30	30	30	59	70	59	100

Propellers Fixation.

The propeller(s) fixation to the shaft is made by:

- Set screws.
- Screwed on ailerons.
- Assembly system through key and washer.
- Cores of two or three elements under pressure on the shaft.
- Welding; for example for agitators that must be rubberized or plasticized.


Pressure screws.




- ✓ Verify that the propeller assembly position, sucking or blowing, is the scheduled.

- ✓ Verify the angular position in the moment of the assembly, if you want to place several propellers on the same shaft.


- ✓ Assemble the propeller(s) on the shaft tightening by the allen screw (see “TIGHTENING TORQUES” section). Be cautious to place the mechanized plan of the shaft in front of the fastening screw.



Screwed on ailerons.




- ✓ Assemble the turbine(s) blade(s) on the lugs welded for that purpose at the end of the shaft using the screws, nuts and washers included in the supply (see “TIGHTENING TORQUE” section)



- ✓ Unless the contrary has been specified, every axial flow propeller will be assembled in blowing position, that is to say, with the propeller entering edge in the upside and turning clockwise looking from the motor to the propeller so that, when turning, they produce a blowing flow that helps to sweep the bottom of the tank.

- ✓ Agitators provided with pitch blade turbines do certainly have reversible flow. To make them work sucking, it is only necessary to reverse the turning direction by changing the position two of the phase wires.




✓ Assemble the turbine(s) blade(s) on the lugs welded for that purpose at the end of the shaft using the screws, nuts and washers included in the supply (see "TIGHTENING TORQUE" section)


✓ Agitators provided with axial flow helicoidal profile mobiles **do not have reversible flow**. To change to sucking position we do not only have to reverse the motor turning direction but also to turn the propeller 180° before fastening it to the shaft, so that the entering edge keeps on the underside. See figures.



Axial flow helicoidal profile.
Rotation direction: Clockwise,
Thrust direction: downward
Standard Bend




Axial flow helicoidal profile.
Rotation direction: anti-clockwise,
Thrust direction: upward
Standard Bend



Axial flow helicoidal profile.
Rotation direction: Clockwise,
Thrust direction: upward
No-standard Bend




Axial flow helicoidal profile.
Rotation direction: anti-Clockwise,
Thrust direction: upward
No-standard Bend




- ✓ Assemble the turbine(s) blade(s) on the lugs welded for that purpose at the end of the shaft using the screws, nuts and washers included in the supply, showing special attention to the position of the existing folds in the blades. These folds should be as shown in the image.

Assembly system through key and washer



- ✓ Mount propeller with bushing on reduced part of shaft as shown in the image. Previously, the key will be mounted in shaft.
- ✓ Insert the shaft in propeller bushing after aligning key and keyway. Tighten using screw and washers included in supply. (See appendix Tightening Torques).


Cores of two or three elements under pressure on the shaft



- ✓ In case of assembling two or three elements on pressure cores, looseness must be evenly distributed when the cores are tightened.

Welding


- ✓ Generally, in mixers whose shafts and propellers need to be coated, propellers are welded directly to the shaft, forming a single piece.
- ✓ If you want to change direction of rotation or flow, you must consult FluidMix.














Lubrication

Description:




- ✓ Next, we describe the oils recommended for the agitator reducers. There are two types of lubrication, **"for life"** lubrication for certain reducers that don't have plugs for filling, emptying or level plug, and lubrication **"with oil"** (**mineral or synthetic**). For these last models oil levels must be respected, they are different depending on to the position of work of the machine.
- ✓ Reducers with lubrication with oil require regular lubricant replacement. The lubricant maintenance interval depends on the oil temperature. See the following graphic:



- ✓ **Ex** Lubricants of explosive atmosphere agitators 'Ex' require ignition temperature greater than or equal to 185°C. Ask [FluidMix](#) in case of lubricant replacement.
- ✓ Replace seals in case of leakage to avoid consequential damage.
- ✓ In reducers with oil input, drain and level plugs should be a regular oil change.
- ✓ To check the oil level in the gearbox, unscrew the oil level plug and check that it overflows through the hole. Screw the level plug again. If necessary, unscrew the filler plug and fill. Immediately clean any discharge of oil using a degreasing agent suitable to the conditions of exploitation.
- ✓ Usually all reducers are filled with mineral oil VG220 or VG460 according to models (consult to [FluidMix](#)), suitable for an ambient temperature of 0 ° C to 40 ° C. For ambient temperatures - 20 and 40 ° C, consult to [FluidMix](#).
- ✓ The amount of existing oil on each reducer depends on working position, size reducer and on some occasions, output speed, so you should consult [FluidMix](#).
- ✓ The lubricants listed in the lubricant table are permissible for reducers. Special lubricants must be used, for example, for long-term storage or special operating conditions.

	Ambient Temperature [°C]			DIN 515173: CLP		Description
	50	0	+50	ISO 129251: CKC/CKD		
 Shell	0		+40		CLP VG 460	Omala 460
	-25		+50 ³⁾		CLP HC VG 320	Omala HD 320
	-10		+50 ³⁾	⊙	CLP HC VG 460	Cassida Fluid GL 460
	-20		+40	⊙	CLP HC VG 220	Cassida Fluid GL 220
	-20		+40		CLP PG VG 220	
	-20		+40		CLP PG VG 460	
	-40	0 4)		❄	CLP HC VG 46	Cassida HF 46
	-20		+40	⊙	CLP PG VG 320	
 Klüber Lubrication	0		+40		CLP VG 460	Klüberoil GEM 1-460 N
	-25		+50 ³⁾	❄	CLP HC VG 320	Klübersynth GEM 4-320 N
	-20		+40		CLP PG VG 460	
	-20		+40		CLP PG VG 220	
	-30	0 4)		❄	CLP PG VG 32	
	-40	0 4)		❄		
	-40			⊙	CLP HC VG 46	Klüber Summit HySyn FG-46
	-20		+40	⊙	CLP HC VG 220	Klüberoil 4 UH1-220N
 FUCHS	-20		+40	⊙	CLP PG VG 320	Klübersynth GEM 2-320
	-25		+50 ³⁾		CLP HC VG 320	Renolin Unisyn CLP 320
	-20		+40	⊙	CLP E VG 320	Plantogear 320 S
	-20		+40		CLP PG VG 460	
 ARAL	0		+40		CLP VG 460	Renolin CLP 460
	-10		+50 ³⁾	⊙	CLP HC VG 460	Eural Gear 460
	-25		+40	⊙	CLP HC VG 220	Eural Gear 220
	-20		+40		CLP PG VG 460	
	0		+40		CLP VG 460	Degol BG 460
	-25		+50 ³⁾		CLP HC VG 320	Degol PAS 320
 Eni	0		+40		CLP VG 460	Blasia 460
	-25		+50 ³⁾		CLP HC VG 320	Blasia SX 320
 bp	0		+40		CLP VG 460	Energol GR-XP 460
	-20		+50 ³⁾		CLP HC VG 320	Enersyn HTX 320
 Castrol	0		+40		CLP VG 460	Alpha MW 460
	0		+40		CLP VG 460	Alpha SP 460
	-20		+40		CLP PG VG 460	Alpha PG 46(β)
 Esso	0		+40		CLP VG 460	Spartan EP 460
	-20		+40		CLP PG VG 460	
	-25		+50 ³⁾		CLP HC VG 320	Spartan Synthetic EP 320
 Mobil®	0		+40		CLP VG 460	Mobilgear 634
	-20		+40		CLP PG VG 460	
	-20		+50 ³⁾		CLP HC VG 320	Mobilgear SHC XMP 320
 LUBCON	0		+40		CLP VG 460	Turmogearoil 460 OM
	-25		+50 ³⁾		CLP HC VG 320	Turmofluid GV 320
	-20		+40		CLP PG VG 460	
	-20		+40		CLP PG VG 220	
	-40	0 4)		❄	CLP HC VG 46	Turmofluid GV 46
	-20		+40	⊙	CLP HC VG 220	Turmosynthoil GV 220
	-20		+40	⊙	CLP PG VG 460	
	-20		+50 ³⁾	⊙	CLP E VG 320	Turmofluid Biolube CLP 320
 Optimag	0		+40		CLP VG 460	Optigear BM 460
	-25		+50 ³⁾		CLP HC VG 320	Optigear Synthetic A 320
	0		+40		CLP VG 460	Tribol 1100/460
	-20		+40		CLP PG VG 460	

Observe the following legend of the lubricant table for the selection of lubricants:

CLP	⇒	Mineral oil
CLP PG	⇒	Polyglycol oil
CLP HC	⇒	Synthetic hydrocarbon or poly-alpha-olefin oil
CLP E		Diester oil (water pollution class 1)
1)		Polyglycol oils cannot be mixed with other oil types
2)		For ambient temperatures higher than 40°C please contact the manufacturer for exact ambient conditions!
3)		Observe critical starting behaviour for low temperatures! For temperatures lower than -25°C special measures for the motor storage and NBR shaft seals are necessary!
		Food-grade lubricant
		Biodegradable lubricant (lubricant for forestry, agriculture and water supply and distribution)
		Low-temperature oils, observe critical starting performance at low temperatures!

WARNING: if the agitator is going to be mounted on a tank for FOOD INDUSTRY or PHARMACEUTICALS INDUSTRY products!


- The lubricants supplied with the reducer gears are according to the USDA-H2 homologation, that means that they may be recommended for food and pharmaceuticals industry, whenever it is impossible a contact with this products.

Should exist an occasional technically unavoidable contact between lubricant and food or products, it is the user's responsibility to fill the reducer gear with a lubricant approved by USDA-H1 standards, in order to avoid a dangerous contamination. FLUIDMIX refuses any claim for damages produced by the non observance of this recommendation


Position of the venting plug, oil input plug and oil drain plug.

Following illustrations show, the position of the venting plugs, filler cap and drain plug oil, depending on the model and position of the gearbox.


Coaxial with helicoidal gears




Hollow shaft with helicoidal gears



Worm gear in horizontal position (mixers HPS3)



Worm gear in vertical position



- ⊗ Breathing / oil filler plug
- Oil drain plug
- Oil-control plug

Start-up

Motors

➤ Description:

All agitators are driven by a motor that can be:

- Electric
- Pneumatic
- Oleohydraulic

In this manual we will see electric motors because they are the most used in most applications.

In case of pneumatic or oleohydraulic motors bear in mind the specific instructions of operation and maintenance supplied with the machine.

➤ Connection and starting:

- ✓ The electrical connection of the Motors must be performed by qualified personnel. Take the necessary measures to prevent any breakdown.
- ✓ It is necessary to carefully check all rating plate values in order to correctly carry out protection and motor connection.
- ✓ Before making any connection check if the voltage and frequency available match that indicated on the nameplate of the motor and check that the motor turns freely by manually moving the fan blades.
- ✓ Check that the section of the cable used is suitable to the voltage, power and distance from the engine up to the connection box.
- ✓ Before commissioning, as well as after a period of prolonged unemployment or a storage it is necessary to check the insulation resistance!. To measure the insulation the main circuit wires must be disconnected.




- ✓ During the measurement, and just after the same, terminals are subject partly to dangerous voltages, so it should not be touched.
- ✓ If possible, the minimum insulation resistance of the winding on the casing of the machine must be measured for a temperature of the winding from 20 to 30° C for other temperatures apply different values for insulation resistance. Measurement must wait until the final resistance (approx. 1 minute) value is reached
- ✓ Insulation resistance, at 25° C, must be greater than the reference value, i.e., 100 MΩ (measured at a voltage of 500 or 1,000 VDC).



- ✓ The housing of the motor must be connected to Earth, and the windings must be discharged by landing to the housing immediately after each measurement, to avoid the risk of electric shock.

- ✓ If the resistance value is not reached, the winding is too humid and must be dried in the oven. The oven temperature should be 90 ° C for a period of 12 to 16 hours, and then 105 ° C for a period of 6 to 8 hours.
- ✓ During heating, plugs the drain holes, if any, must be removed. Closing valves, if any, must be open. After heating, make sure to replace the plugs.
- ✓ Even if there are drain plugs, it is recommended to remove the shields and covers cases of terminals for the drying process.
- ✓ Normally, if the moisture is caused by sea water, the engine must be wound again.
- ✓ Motors should always operate with the fan cowl mounted in his position; the grid of the top must be free from obstructions to avoid excessive heating of the motor.
- ✓ Attention: FluidMix declines any responsibility on machines that have not been installed respecting the safety regulations in force. This circumstance also nullifies the warranty of the agitator.




- ✓ Standard motors are supplied with a connection box of 6 terminals, allowing connection star or triangle according to the position of the bars. In the case of special motors (single phase, two-speed, etc...), with different terminal box or starters/Delta refer specific operating and maintenance instructions that must accompany the machine.
- ✓ Properly connect the ground terminal, which can be inside of the terminal box or on the motor housing.
- ✓ Start the equipment checking the absence of noise and vibration

- ✓ Normal conditions for continuous service are:
 - Room temperature till +40°C
 - A higher room temperature reduces the nominal power (to approximately the 80% for a temperature of 60°C)
 - Height over the sea level up to 1000 m
 - A bigger height reduces the nominal power to approximately 8% for each supplementary 1000 m.
 - The maximum temperatures in the hottest points of the winding are for class B: 125°C, class F: 155°C and class H: 180°C

➤ **Connection of temperature monitoring**

Motors provided with a terminal box to connect the temperature monitoring must be connected according to the following electrical wiring diagram.



Description	Designation in accordance with EN 60034-8	Note
Thermal contact TCO	TB1	TB1 Max. 250 V~
	TB2	TB2 Max. 1.6 A~

Variable-speed driver

➤ Description:

Variable-speed drive is used to control motor speed and torque by varying motor input frequency.

➤ Applications:

- ✓ It is installed in those equipments where it is necessary to adjust the turning speed with accuracy depending on the process.
- ✓ It can be placed near the agitator, in a control house or in an electric panel.

➤ Assembly and starting:

- ✓ Put the variable speed drive in a ventilated place without humidity or dust, exempt from metallic particles, vibrations, electromagnetic influences and far from fluorescent lamps.
- ✓ Use the variator with a room temperature between -10°C and $+40^{\circ}\text{C}$
- ✓ Always connect the variator to ground to avoid accidents and operation problems.
- ✓ Verify that the voltage available coincides with the one necessary and it does not have oscillations higher to the 10% of the nominal. In powers up to 1.5 kW. The feed voltage to the variator is usually single phase; the output voltage is always three-phase. Pay attention to the feeding connection of the variators, because if they are single phase and they are connected as three phases, damages are irreparable and under no circumstance they would be under [FluidMix's](#) guarantee. Check in the manufacturer's variator manual, included with the equipment, the connection schemes.
- ✓ Connect the three phases of the motor to the converter terminal. The motor must be fed exclusively from the variator and any type of switch or commutator must be avoided in the wire that connects them.
- ✓ Always connect the motor to ground through the converter terminal.
- ✓ Start the converter and verify the maximum and minimum range of speed attainable (measured with a tachometer). This range must coincide with the one specified on the equipment offer. If it is not like that, immediately contact [FluidMix](#) because if the agitator turns at a higher or lower speed than the ones scheduled, that could lead to serious damages to it and to the installation.

Reducers

➤ Description:

Reducers for agitators can be:

- Coaxial with helicoidal gears.
- Hollow shaft with helicoidal gears
- Right-angled with hollow shaft and helicoidal gears.
- Worm gear.
- "Tandem" type with parallel shafts for high torque and bending moment

➤ Use:

- ✓ It can be assembled on any type of agitator either vertical or horizontal when the turning speed required for the shaft is different to the motor speed and constitutes one of the main pieces of these machines.
- ✓ In most cases the reducer bearings are the ones which support the radial and axial stresses generated with the turning of the propeller(s) whether this is vertical or horizontal. That is why these reducers are always specially designed, not only to transmit a torque, but to be able to absorb axial stresses and bending moments.
- ✓ When the agitator shaft is very long or the power to transmit is high a guided lantern is required after the reducer; in this case the bearings of that lantern are the ones that absorb the stresses and the reducer must be exclusively designed to transmit a twisting torque with your specific service factor.
- ✓ The service factor of a reducer is the relation between the maximum transmissible power and the power absorbed by the mobile when it turns inside a liquid. Anyway the transmissible power for the reducer must be higher than the installed motor power.
- ✓ The maximum normal temperature in the frame for reducers with cylindrical gears is 65/70 °C and for worm gear reducers till 85 °C. For higher temperatures consult [FluidMix](#).
- ✓ The maximum noise level must not exceed 85 dB for powers less than 37 kW.


➤ Assembly and starting:

- ✓ After having verified the points detailed on "MOTORS" section, check that the reducer is firmly anchored and that it has got the specific oil inside. See "LUBRICATION" section.
- ✓ The type of lubrication recommended is shown on a label stuck to the reducer where it will be indicated "Full of oil" or "Life lubricated".
- ✓ All reducers are supplied with the oil needed; nevertheless if for any reason the lubricant is sent apart that will be indicated on the reducer to fill it before starting.
- ✓ In reducers lubricated by oil, verify that the level is suitable to the mounting position. In the lubricant input hole it is necessary to put a drilled plug, supplied with the equipment, to allow the degassing. In any work position the tankfull plug must be the one with the degassing hole.




- ✓ To prevent build-up of excessive pressure, sealed vents must be activated as shown prior to gear unit start up.

1. WARNING!!



2.



- ✓ In any working position, the hole where the venting plug is located is the lubricant filling hole.
- ✓ Once the equipment is on service, verify the absence of abnormal noises or vibrations in the reducer, as well as its tightness and observe if there is any leak of lubricant. The frame temperature must be controlled after some time of work.

Sealing systems

➤ Description:

The main types of sealing systems used in agitators are:

- Lip seal for vertical mounting
- Stuffing box on replaceable jacket with refrigeration or greasing; horizontal or vertical mounting.
- Simple mechanical seal; horizontal mounting in contact with the product or vertical mounting turning dry according to peripheral speed limits, pressure or temperature.
- Double mechanical seal with or without incorporated bearing; it is essential to use refrigeration. This system can support high pressures and temperatures.

➤ Applications:

- ✓ They must be always used when it is wanted to isolate the content of a tank from the atmosphere, either due to the pressure inside, to the temperature, to the product toxicity or of its vapours, etc ...
- ✓ Vertical or horizontal agitators.

➤ Mounting and starting:

- ✓ Lip seal. Start the agitator; no special requirement.

- ✓ Stuffing box. Fasten the screws of the press cover till avoid vapours or liquid leaks, but never fasten thoroughly or block.
- ✓ Stuffing box with grease cup. Apply 4 bumps of lubrication pump each 1000 hours.
- ✓ Stuffing box with refrigeration. Make a liquid compatible with the product and with the vapours in the tank pass through the connections for the purpose.
- ✓ Simple mechanical seal in vertical agitator. Start the agitator; no special requirement.
- ✓ Simple mechanical seal in horizontal agitator. Start the agitator only if you are sure that the liquid level in the tank is over the seal because it is the own liquid which must refrigerate it. Never make it turn dry!
- ✓ Double mechanical seal:
 - Dismount the fixation for transport that carries the shaft jacket (small plates, screws, etc...) according to the specific instructions enclosed with the machine.
 - It is necessary foresee an external lubrication and/or refrigeration system, that can be supplied on request by [FluidMix](#). See detail on "THERMOSIPHON" section.

Thermosiphon

➤ Description and applications:

Equipment basically comprised of the following elements:

- ✓ Stainless steel container (approx. volume 5 l.)
- ✓ Connection tubes for input and output of the product towards the mechanic seal cartridge.
- ✓ Level small window or connections for it.
- ✓ Connections for cooling coil (optional).
- ✓ Connections for circuit filling with its corresponding valves.
- ✓ Connections for pressurizing with nitrogen.
- ✓ Connections for control manometer.
- ✓ Draining connection.

➤ Connection and starting:

- ✓ Proceed to mount the system at a level superior to the mechanic seal cartridge by verifying that there are not solid residues that may cause jamming.
- ✓ Connect the tubes to the seal trying to avoid elbows and abrupt changes of direction. The forward tube from the seal to the thermosiphon will be connected in the upside; the return one in the underside.
- ✓ Fill the system through the input connection with clean liquid, free of particles in suspension and compatible with the product in the tank and compatible, moreover, with the faces materials and the seal joints, till the level of the product is seen through the small window.
- ✓ Pressurize with nitrogen through the scheduled connection till achieve a pressure superior in 1 or 2 bar to the existing one inside the tank.
- ✓ In case of operation of the seal under a temperature superior to 100° C, connect a cooling water line to the thermosiphon inner coil (optional).

Comissioning of mixer



- ✓ Each agitator model has been designed to obtain the maximum performance in your specific application. Be sure to mount the corresponding agitator according to technical specifications or drawings of overall dimensions.
- ✓ If the conditions of the process such as density, viscosity, temperature, pressure... vary, it must be checked by [FluidMix](#) suitability of the agitator.
- ✓ Verify the existence of no obstacles near the shaft and agitator turbine.
- ✓ A flow stream should never flow directly of on the shaft and the propeller of the agitator. If necessary, deflection screens should be positioned.
- ✓ Do not make modifications to the agitator (change engine, speed of the agitator, shaft length, diameter propellers...), without consulting [FluidMix](#). Any modification may alter the functioning of the agitator, causing serious damage.
- ✓ If any problems with the agitator, check the installation and read the section "Problems, possible causes and solutions". If this still does not solve the problem, please contact [FluidMix](#).


➤ Before starting IS ESSENTIAL to check the following points:



- ✓ The motor voltage which is written on the characteristics plate and which depends on the connection way must be the same that the one that we have in the grid.
- ✓ The mechanic and thermal protections of the motor must be the needed ones.




- ✓ The motor frame must always be connected to ground
- ✓ Take apart the fan protection of the motor and turn the fan with your hand to check that there are no hard points and that the propeller turns free. Assemble the fan protection verifying that the ventilator protection cover is free of obstructions.



- ✓ Check that the speed reducer (if there is one) has a suitable oil level.
- ✓ To prevent build-up of excessive pressure, sealed vents must be activated as shown prior to gear unit start up.

!WARNING!



- ✓ Check that the screws of the coupling that join the agitator head with the shaft are appropriately tightened. In case of rigid coupling plates, before accomplishing the assembly it is necessary to remove any trace of paint, varnish or dirt from the faces which are going to be in contact.
- ✓ Check the correct tightening of the screws that fasten the propeller.



Trouble-shooting

Problems	Possible cause	Action
Motor overload	Viscosity of the liquid too high	Decrease the viscosity
	High density	Increase the power of the motor
Insufficient agitation	Viscosity of the liquid too high	Decrease the viscosity
	Oversized tank for selected agitator	Consult technical department.
	Wrong direction of rotation	Reverse the direction of rotation
	Agitator speed too low.	Increase the speed
	Turbine mounted in wrong way.	Correctly mount the turbine.
Noisy operation	Worm or damaged parts	Check bearings and gears for excessive wear. Replace worn parts. Try to find cause of wear. Check for water and/or abrasives in oil, overload, incorrect rotation, excessive shock,
	Overloading	Check process fluid (specific gravity and viscosity) vs. design conditions. Check agitator speed and impeller diameter against unit assembly drawing information.
	Worn motor shaft	Check the correct fitting of the motor reducer. Check worn parts.
	Structural vibration and sound amplification	Steel mounting structures often amplify small amounts of normal noise into excessive noise. This can be corrected by adding stiffness or sound deadening material to the structure.
	Insufficient or in-existent liquid level.	Check out liquid level in the tank.
	Bent shaft.	Replace shaft.
	Critical speed	Consult the technical department.
Abnormal Heating	Oil leak	Add lubrication oil.
	Incorrect oil	Review Lubrication section of manual. Replace with proper oil.
	Unusual ambient	Units installed in a hot area of a plant where air flow is restricted can overheat. Remove obstruction and if necessary force circulate air.
	Improper oil level	Add or remove oil.
	Cleanliness	Remove dirt and/or product buildup from motor/gear drive.
Shaft does not rotate while the engine is running	Break of the motor shaft or gears of the reducer.	Consult the technical department.
Damaged retainer	Replace retainer	If the retainer is worn it must be replaced. Consult technical department.



Contact [FluidMix](#) immediately in case problems with the agitator persist.

Maintenance

Motor

- ✓ Most motors with frame smaller than 160 or 200 (see the marks) have got "life greased" bearings.
- ✓ Motors with bigger frame have got oiler(s). This system allows renewing the grease with the motor working, lubrication is recommended each 1000 hours in normal operation conditions. Consult "RECOMMENDED OILS AND GREASES" section.
- ✓ Keep the ventilator cover free from strange objects to assure right refrigeration of the frame blades.
- ✓  Motor and bearings are potentially ignition points in explosive atmospheres, that is why these parts need to be part of an exhaustive preventive maintenance plan. Before assembling spare parts and repair parts, it must be informed to FluidMix and then supervised by FluidMix.
- ✓  Periodically and after long not-working period, motor must be cleaned to avoid dust accumulation and product agglomeration on mobile parts, such as shaft, and over its cover.

Reducer

- ✓ No maintenance for "life lubricated" reducers.
- ✓ For reducers lubricated with oil, empty after the first 500 hours of work letting oil flow out through the outlet hole till all the impurities produced by the tread have been dragged. After this period, change each 2500 hours of work or every 6 months, what happens first using mineral oils. Using synthetic oils (see tables on "LUBRICATION" section) the period to change is 12000 hours of work (always after the first 500 hours) or every 30 months, what happens first.
- ✓ In case of apparition of vibrations or abnormal noises, substitute the faulty piece(s) asking FluidMix for a spare parts list.
- ✓  Reducer is other important potentially ignition point in explosive atmospheres, that is why it must be part of an exhaustive preventive maintenance plan. Before assembling spare parts and repair parts, it must be informed to FluidMix and then supervised by FluidMix.
- ✓  Periodically and after long not-working period, reducer must be cleaned to avoid dust accumulation and product agglomeration on mobile parts, such as shaft, and over its cover.

Sealing systems

- ✓ Lip seal. No maintenance; substitute in case of wear.
- ✓ Stuffing box. Fasten softly the cover when there are leaks. Before the cover reach the limit of its way because of the rings wear, add a new ring of suitable material and quality.
- ✓ Simple mechanical seal. Substitute rub faces and joints when they are worn, ask FluidMix for a spare parts list.
- ✓ Double mechanical seal. Dismount the whole cartridge to substitute the worn elements. This operation must be made in a specialized workshop, so it is convenient to send it to FluidMix for its repair and tests.

Thermosiphon:

- ✓ Verify periodically the level and the circuit pressure in the thermosiphon. Its decrease can mean that there is a deterioration in the seal and that there are leaks in its faces.

Shafts and turbines

- ✓ The emergence of abnormal vibrations is symptom of imbalance on the shaft or in the propeller or gaps in the guidance. Proceed to replace the defective(s) part(s) requesting a spare parts list to [FluidMix](#).
 - ✓ Check regularly that the propeller or the connecting of this to the axis elements are clean and free of debris.
 - ✓ Make sure that shafts and propellers are free of snags with existing elements in the interior of the tank.
- ⚠ In general terms, preventive maintenance of every agitator component must include periodical cleaning that guarantees rust and dust absence in the hole agitator and specially in parts with metal-to-metal contact.
- ⚠ Re-painting processes must respect carefully original metal-to-metal contacts, as a guarantee of an effective ground connection of all parts to ensure the absence of electrostatic discharges which are a potentially risk of ignition in explosive atmospheres. In any event, this must be asked and advised by [FluidMix](#). Total painting thickness can not be greater than 2mm.

Technical data sheets and spare parts list

- ✓ Next, you can find data sheets of standard range mixers of [FluidMix](#). For other models, please contact with [FluidMix](#).
- ✓ If you need spare parts, consult lists of spare parts, or if you prefer, contact [FluidMix](#), providing data from the nameplate.
- ✓ For those special models, contact [FluidMix](#) to request the corresponding sheet.

VHS3 SERIES**Description:**


The smallest mixers of our range are the VHS agitators. They are fast running mixers, available in three speeds: 750, 1000 and 1500 rpm, and are suitable for little tanks, with volumes from 50 to 1000 liters. Appropriate for chemicals, dissolutions, non viscous liquids. The standard mobile is a three blades marine propeller. Simplicity and economy are characteristics of VHS mixers. The propeller can be easily adjusted along the shaft if necessary, or it can be equipped with two or more propellers.

Main features:

- For tanks 50 – 1000 liters.
- Motor power: 0,12 kW to 0,55 kW.
- Running speed 750, 1000, 1500 rpm.
- 3 blades marine propeller diameters 80 to 140 mm.
- Shaft diameter 15 or 20 mm, length up to 800 mm.
- Shaft and propeller AISI 316, or polyethylene coated.
- Fixation flange with double lips oil seal.

Optional extras:


- AISI 316 flange.
- Special coatings at shaft + propeller.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.



WARNING: VHS mixers cannot run in empty tanks!

Model	Power kW	Speed rpm	A	D	L max.	N	P	S	Weight kg
VHS3-00 03 B 00	0,12	1500	188	80	500	100	120	7	7
VHS3-01 01 B 01	0,18	750	240	100	800	130	160	10	15
VHS3-01 02 B 02	0,18	1000	188	128	800	130	160	10	12
VHS3-02 03 B 01	0,25	1500	216	100	800	130	160	10	11
VHS3-03 03 B 02	0,37	1500	246	128	800	130	160	10	12
VHS3-04 02 B 03	0,55	1000	246	140	800	165	200	11	15

VHS3 Exploded view drawing
Solution S1 Solution S2 Solution S3



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
1a	4	SCREWS, WASHER AND NUTS	
2	1	SLEEVE	AISI 316
2a	2	SCREWS A2 DIN916	ASSEMBLY SLEEVE TO MOTOR SHAFT
2b	2	SCREWS A2 DIN916	ASSEMBLY SHAFT TO SLEEVE
3	1	FLANGE	PVC OR AISI316
4	1	RETAINER	NBR OR VITON
5	1	SHAFT	AISI 316 (OPTIONAL AISI 316+PE)
6	1	MARINE PROPELLER	AISI 316 (OPTIONAL AISI 316+PE)
6a	1	SCREW A2 DIN916	ASSEMBLY HELICE TO SHAFT

VHD3 SERIES


VHD3 fast running mixers available in three speeds: 750, 1000 and 1500 rpm, and suitable for little and medium tanks, with volumes from 200 to 3000 liters. The standard mobile is a three blades marine propeller. An aluminium lantern with a bearing guided inner shaft absorbs the radial forces and allows to reach shaft lengths up to 1500 mm. The propeller can be easily adjusted along the shaft if necessary, or it can be equipped with two or more propellers.

Main features:

- For tanks 200 – 3000 liters.
- Motor power: 0,18 kW to 1,5 kW.
- Running speed 750, 1000, 1500 rpm.
- 3 blades marine propeller diameters 128 to 200 mm.
- Shaft diameter 20 mm, length up to 1500 mm.
- Shaft and propeller AISI 316, or polyethylene coated.
- Flange with 2 mounting options: 110 and 130 circle of bores.


Optional extras:

- AISI 316 or PVC flange with oil seal.
- Special coatings at shaft + propeller.
- Food industry execution, polished.
- ATEX, or pneumatic motors.
- DIN or ANSI flanges.



WARNING: VHD mixers cannot run in empty tanks!

Model	Power kW	Speed rpm	A	D	L max.	Weight kg
VHD3-01 02 B 01	0,18	1000	188	100	1500	17
VHD3-03 03 B 02	0,37	1500	216	128	1500	17
VHD3-05 03 B 03	0,75	1500	232	140	1500	20
VHD3-06 03 B 04	1,1	1500	267	160	1500	21
VHD3-07 03 B 05	1,5	1500	267	200	1500	26



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
1a	4	SCREWS, WASHER AND NUTS	
2	1	BEARING SLEEVE	
2a	2	BEARING REF. 6256 2RS	
2b	1	SCREW A2 DIN916	
3	1	PALIER	ALUMMINIUM
4		OPTIONAL FLANGE	PVC OR AISI 316
4a	1	RETAINER	NBR OR VITON
5	1	SHAFF	AISI 316 (OPTIONAL AISI 316+PE)
6	1	MARINE PROPELLER	AISI 316 (OPTIONAL AISI 316+PE)
6a	1	SCREW A2 DIN916	

VPP3 SERIES


VPP series are low running mixers specially designed for the mixing of quite viscous fluids. They are suitable for medium volume tanks up to 4 - 5 m³. Thanks to their life greased reducer gear it is a friendly maintenance machine just to connect and run. The S type axial profile propeller is designed to reach a balanced pumping flow/power absorption ratio. The propeller can be easily adjusted along the shaft if necessary, or it can be equipped with two or more propellers.

Main features:


- For tanks 0,5 – 5 m³.
- Motor power: 0,18 kW to 2,2 kW.
- Running speed 300 rpm (other speeds available).
- 3 blades type S axial profile propeller, diameter 200–400 mm.
- Shaft length up to 1500 mm.
- Shaft and propeller AISI 316, or polyethylene coated.

Optional extras:

- PVC or AISI 316 flange with oil seal.
- Rubber coated shaft + propeller.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.
- Special executions.



Model	Power kW	Speed rpm	A	B	D	L max.	N	P	Weight kg
VPP3-01 03 B 01	0,18	310	188	111	200	1000	165	200	18
VPP3-02 03 B 01	0,25	300	207	144	200	1500	165	200	22
VPP3-03 03 B 25	0,37	309	207	144	250	1500	165	200	24
VPP3-05 03 B 02	0,75	309	225	148	300	1500	210	250	30
VPP3-06 03 B 03	1,1	313	275	179	350	1500	210	250	42
VPP3-07 03 B 03	1,5	316	275	179	350	1500	210	250	43
VPP3-08 03 B 04	2,2	316	275	179	400	1500	210	250	44



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	NORMALLY 315rpm
2a	4	SCREWS AND WASHERS	
3	1	FLANGE	CARBON STEEL (OPTIONAL AISI 316)
4	1	SLEEVE	
4a	2	SCREWS A2 (KEY IN VPH3 SERIES)	
4b	1	SCREW, WASHER DIN 125	
5	1	SHAFT	AISI 316 (OPTIONAL AISI 316+PE)
6	1	TYPE "S" PROPELLER	AISI 316 (OPTIONAL AISI 316+PE)
6a	3	SCREW A2 DIN916	

VTA SERIES


The main characteristic of VTA4 mixers is their four foldable blades axial turbine. Axial turbine achieves a strong mixing effect in tanks from 1 to 4 m³ volume. Standard running speeds are 100 to 150 rpm. Thanks to their life greased reducer gear it is a friendly maintenance machine just to connect and run. VTA4 mixers can be equipped with more than one single turbine.

Main features:

- For tanks 1 – 4 m³
- Motor power: 0,37 kW to 2,2 kW.
- Running speed 75 to 150 rpm.
- 4 foldable blades axial turbine.
- Shaft and propeller AISI 316.


Optional extras:

- Optional support for IBC/GRG tanks.
- AISI 316 or PVC plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.



Model	Power kW	Speed rpm	A	B	D	L Max.	N	P	S	Weight kg
VTA4-03 03 B 00	0,37	126	207	204	400	800	160	200	22	22
VTS4-05 03 B 00	0,75	125	207	234	400	800	210	250	22	28
VTA4-										
VTA4-										

Data according to specific requirements of each application.



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	NORMALLY 125 rpm
2a	4	SCREWS AND WASHERS	
3	1	FLANGE	CARBON STEEL (OPTIONAL AISI 316)
4	1	SLEEVE	CARBON STEEL (OPTIONAL AISI 316)
4a	2	SET SCREWS A2	DIN 916
4b	1	SCREW AND WASHER	AISI 316
5	1	SHAFT	AISI 316
6	1	FOLDABLE BLADES AXIAL TURBINE	AISI 316
6a	2	SET SCREW A2	DIN 916

VTS4-VTH4 SERIES


The main characteristic of VTS4 mixers is their four blades axial turbine. Axial turbine has a high power input ratio, and achieves a strong mixing effect in tanks from 4 to 15 m³ volume. Standard running speeds are 75 to 150 rpm. The rotation sense of the turbine can be easily changed just changing motor power feed wires. Thanks to their life greased reducer gear it is a friendly maintenance machine just to connect and run. VTS4 mixers can be equipped with more than one single turbine.

Main features:



- For tanks 4 – 15 m³.
- Motor power: 0,37 kW to 2,2 kW.
- Running speed 75 to 150 rpm.
- 4 blades pitched axial turbine, diameters 400 to 800 mm.
- Shaft length up to 2500 mm.
- Shaft and propeller AISI 316, AISI 304, carbon steel, rubber coated.

Optional extras:

- AISI 316 or PVC plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.



Model	Power kW	Speed rpm	A	B	D	L max.	N	P	S	Weight kg
VTS4-02 02 C 00	0,25	96	207	184	400	2000	230	280	16	50
VTS4-03 02 C 01	0,37	96	207	184	500	2500	230	280	16	65
VTS4-05 02 C 02	0,75	96	225	190	600	2500	250	300	16	80
VTS4-07 02 C 03	1,5	99	275	212	700	2500	250	300	16	115
VTS4-08 02 C 04	2,2	99	309	212	800	2500	250	300	16	120



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	NORMALLY 100rpm
2a	4	SCREWS AND WASHERS	
3	1	FLANGE	CARBON STEEL (OPTIONAL AISI 316)
4	1	SLEEVE	DIN916
4a	2	SCREWS A2 (CHAVETA EN VPH3)	
4b	1	SCREW, WASHER DIN 125	
4c	1	KEY	
5	1	SHAFT	ACCORDING TO NEED
6	4	LUGS	ACCORDING TO NEED
6a	8	SCREWS, WASHERS AND NUTS	ACCORDING TO NEED
7	4	BLADES AXIAL TURBINE	ACCORDING TO NEED

VPT3 SERIES


VPT3 mixers have three blades axial profile T type. They are suitable for big tanks, and can be optionally equipped with a lantern and any type of sealing, like stuffing box, dry or refrigerated mechanical seals, hydraulic labyrinth, etc. The VPT are custom made mixers, and each of them is studied and designed for their specific application. Reducer gears may be helical gears type, or parallel shaft. Shafts longer than 6 meter may be executed in two or more pieces. VPT mixers can have two or more propellers on the shaft. Flow direction and turning sense can be chosen.

Main features:


- For big tanks.
- Motor power: 0,55 kW to 45 kW.
- Running speed 30 to 150 rpm.
- 3 blades axial profile T type, diameters 800 to 4000 mm.
- Shaft length up to 12000 mm.
- Shaft and propeller AISI 316, AISI 304, carbon steel, rubber coated, special alloys.

Optional extras:

- AISI 316 or coated plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.
- Lantern with sealing: stuffing box, mechanical seal, hydraulic labyrinth.
- Cooled fixation plate.



Model	Power kW	Speed rpm	A	B	C	D	L	N	P	S	Weight kg
VPT3-											
VPT3-	Data according to specific requirements of each application .										



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	
2a	4	SCREWS AND WASHERS	
3	1	SQUARE PLATE	CARBON STEEL (OPTIONAL AISI 316)
4a	2	SCREWS AND WASHERS	
4b	1	KEY	
5	1	SHAFT	ACCORDING TO NEED
6	3	LUGS	ACCORDING TO NEED
6a	12	SCREWS, WASHERS AND NUTS	ACCORDING TO NEED
7	3	TYPE "T" PROPELLER	ACCORDING TO NEED

VPS3 SERIES


VPS3 mixers have three blades axial profile S type. That profile performances a great pumping volume with a quite low absorbed power. They are suitable for big tanks, and can be optionally equipped with a lantern and any type of sealing, like stuffing box, dry or refrigerated mechanical seals, hydraulic labyrinth, etc. The VPS are custom made mixers, and each of them is studied and designed for their specific application. Reducer gears may be helical gears type, or parallel shaft. Shafts longer than 6 meter may be executed in two or more pieces. VPS mixers can have two or more propellers on the shaft. Flow direction and turning sense can be chosen.

Main features:


- For big tanks.
- Motor power: 0,55 kW to 45 kW.
- Running speed 30 to 150 rpm.
- 3 blades axial profile T type, diameters 800 to 4000 mm.
- Shaft length up to 12000 mm.
- Shaft and propeller AISI 316, AISI 304, carbon steel, rubber coated, special alloys.

Optional extras:

- AISI 316 or coated plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.
- Lantern with sealing: stuffing box, mechanical seal, hydraulic labyrinth.
- Cooled fixation plate.



Model	Power kW	Speed rpm	A	B	C	D	L	N	P	S	Weight kg
VPS3-											
VPS3-			Data according to specific requirements of each application .								



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	
2a	4	SCREWS AND WASHERS	
3	1	SQUARE PLATE	CARBON STEEL (OPTIONAL AISI 316)
4a	2	SCREWS AND WASHERS	
4b	1	KEY	
5	1	SHAFT	ACCORDING TO NEED
6	3	LUGS	ACCORDING TO NEED
6a	3	SCREWS, WASHERS AND NUTS (SET)	ACCORDING TO NEED
7	1	TYPE "S" PROPELLER	ACCORDING TO NEED

VFR3 SERIES


VFR3 flocculators have three blades axial profile S type. That profile performances a great pumping volume at low speed with a quite low absorbed power. They are suitable for big tanks, and can be optionally equipped with a lantern and any type of sealing, like stuffing box, dry or refrigerated mechanical seals, hydraulic labyrinth, etc. The VFR3 are custom made mixers, and each of them is studied and designed for their specific application. Reducer gears may be helical gears type, or parallel shaft. Longer than 6 meter shafts may be executed in two or more pieces. VFR3 mixers can have two or more propellers on the shaft. Flow direction and turning sense can be chosen.

Main features:


- Flocculation.
- Motor power: 0,18 kW to 15 kW.
- Running speed 5 to 50 rpm.
- 3 blades axial profile S type, diameters 400 to 4000 mm.
- Shaft length up to 12000 mm.
- Shaft and propeller AISI 316, AISI 304, carbon steel, rubber coated, special alloys.

Optional extras:

- AISI 316 or coated plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.
- Lantern with sealing: stuffing box, mechanical seal, hydraulic labyrinth.



Model	Motor kW	rpm	A	B	C	D	L	N	P	S	Weight kg
VFR3-											
VFR3-	Data according to specific requirements of each application .										



POS.	QTY.	DESCRIPCION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
2	1	REDUCER	
2a	4	SCREWS AND WASHERS	
3	1	SQUARE PLATE	CARBON STEEL (OPTIONAL AISI 316)
4	1	COUPLING	CARBON STEEL (OPTIONAL IN OTHER MATERIALS)
4a	1	SCREW AND WASHERS	
4b	4	SCREWS, WASHERS DIN 125, GROWER WASHERS DIN 127	
5	1	SHAFT	ACCORDING TO NEED
6	3	LUGS	ACCORDING TO NEED
6a	3	SCREWS, WASHERS AND NUTS SET	ACCORDING TO NEED
7	1	TYPE "S" PROPELLER	

VFT2 SERIES


VFT mixers are specific for flocculation processes. They are equipped with two or three blades axial turbine blades with great blade surface, to develop a great flow rate at slow speed. Each VFT mixer is specially designed for an optimum adapting to the tank geometry. Longer than 6 meter shafts may be executed in two or more pieces. VFT mixers can have two or more propellers on the shaft. Flow direction and turning sense can be chosen.

Main features:


- For big tanks.
- Motor power: 0,25 kW to 3 kW.
- Running speed 5 to 40 rpm.
- 2/3 blades axial profile F type diameters 400 to 4000 mm.
- Shaft length up to 12000 mm.
- Shaft and propeller AISI 316, AISI 304, carbon steel, rubber coated, special alloys.

Optional extras:

- AISI 316 or coated plate with oil seal.
- Food industry execution, polished.
- ATEX motors.
- DIN or ANSI flanges.



Model	Motor kW	rpm	A	B	C	D	L	N	P	S	Weight kg
VFT2-											
VFT2-	Data according to specific requirements of each application .										



POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO MODEL MIXER)
2	1	REDUCER	
2a	4	SCREWS AND WASHERS	QUALITY 8.8
3	1	SQUARE PLATE	CARBON STEEL (OPTIONAL AISI 316)
4a	1	SCREW AND WASHERS	QUALITY 8.8
4b	1	KEY	
5	1	SHAFTS	ACCORDING TO NEED
6	2	LUGS	ACCORDING TO NEED
6a	3	SCREWS, WASHERS AND NUTS SET	ACCORDING TO NEED
7	2	VFT BLADES	ACCORDING TO NEED

L SERIES


FluidMix creates special designs for those agitators used in processes that need a sealing system. These special designs are composed by a lantern that host the suitable sealing system for the process.


Main features:

- These designs can be implemented in all series of our agitators.
- For tanks containing pressurized products and high temperature, toxic products,...
- Dimensions and materials according to specific requirements of the process.
- Sealing systems available: Gland seal, labyrinth seal, mechanical seal or double mechanical seal,...

Optional extras:

- Food industry execution, polished.
- ATEX motor and ATEX certificate if it is mandatory.
- DIN or ANSI flanges.
- Disassembling of mechanical seal with pressurized tank in case the process requires it.





POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO MODEL MIXER)
2	1	REDUCER	ACCORDING TO NEED
2a	4	SCREWS AND WASHERS	QUALITY 8.8
3	1	LANTERN	CARBON STEEL (OPTIONAL AISI 316)
4	1	MECHANICAL SEAL	QUALITY 8.8
5	1	FLANGE	CARBON STEEL (OPTIONAL AISI 316)
6	1	SHAFTS	ACCORDING TO NEED
7	1	PROPELLER / TURBINE	ACCORDING TO NEED
8	1	DISASSEMBLING SYSTEM OF MECHANICAL SEAL IN CASE OF TANKS WITH FULL LOAD OR PRESSURE	ACCORDING TO NEED

HPS3 SERIES


The HPS3 series are side entry mixers. They are very appreciate in wine industry, breweries, dairies, and mainly in big volume storage tanks from 10 to 500 m³, or even more, to keep non viscous liquids homogenously. A mechanical seal, normally silicon carbide/viton, ensures a leakage free work. The propeller is a 3 blades axial profile type S. Standard execution has a stainless steel DIN fixation flange. As option the mixer can be performed with an additional emergency sealing flange to avoid liquid leakages in case of any damage in the mechanical seal, until the seal can be repaired. A more sophisticated system, allows to do maintenance works (sealing change) without the need of emptying the tank.

Main features:


- For tanks 10 – 100 m³.
- Motor power: 0,75 kW to 3kW.
- Running speed 290 rpm.
- 2 blades axial profile,
- diameters 250 to 450 mm.
- Silicon carbide mechanical seal.
- Shaft and propeller AISI 316, AISI 304.

Optional extras:

- Emergency sealing flange.
- Full tank maintenance device.
- Food industry execution, polished.
- ATEX motors.
- ANSI flanges.



Model	Power kW	Speed rpm	A	B	D	L	N	P	ZxS	Weight kg
HPS3-05 16 B 40	0,75	200	306	235	400	550	210	250	8x18	40
HPS3-07 16 B 45	1,5	200	380	236	450	600	240	285	8x22	55
HPS3-08 16 B 50	2,2	200	436	288	500	650	295	340	8x22	85
HPS3-09 16 B 54	3	200	452	298	540	690	295	340	8x22	85
HPS3-11 16 B 60	5,5	200	618	354	600	750	350	395	12x22	150
HPS3-12 16 B 66	7,5	200	635	354	660	810	350	395	12x22	165





POS.	QTY.	DESCRIPTION	REMARKS
1	1	MOTOR	POWER (ACCORDING TO AGITATOR MODEL)
1a	4	SCREWS, WASHERS AND NUTS	
2	1	REDUCER	NORMALLY 315rpm
2a	4	SCREWS AND WASHERS	
3	1	FLANGE	CARBON STEEL+ AISI 316
4a	1	STATIC PART (MECHANICAL SEAL)	
4b	1	ROTATING PART (MECHANICAL SEAL)	
5	1	SHAFT	AISI 304 OR AISI 316
5a		SCREW AND WASHERS	
5b		KEY	
6	1	TYPE "S" PROPELLER	AISI 304 OR AISI 316
6a	1	KEY	
6b	1	SCREW AND WASHERS	

Reducer section


Coaxial with helicoidal gears

Hollow shaft with helicoidal gears



POS.	DESCRIPTION	POS.	DESCRIPTION	POS.	DESCRIPTION
101	HOUSING	125	SHAFT SEAL	154	SHIM
102	COVER / HOUSING	126	RING	155	SHIM
103	GEAR	127	SHAFT SEAL	156	SHIM
104	PINION SHAFT / WORM SHAFT	128	SHAFT SEAL	157	SHIM
105	GEAR / WORM GEAR	129	SHAFT SEAL	158	BUSHING
106	HOLLOW SHAFT / SHAFT	130	COVER	159	SHIM
107	SHAFT / BUSHING	131	COVER	160	JOINT
108	SHAFT	132	COVER	161	JOINT
109	FLANGE	135	KEY	170	ALLEN SCREW
110	FLANGE	136	KEY	171	ALLEN SCREW
111	FOOT (ONLY GFL)	139	CIRCLIP	172	ALLEN SCREW
111	BEVEL GEAR SET (ONLY GKS)	140	CIRCLIP	173	ALLEN SCREW
112	SHRINK DISK	141	CIRCLIP	174	ALLEN SCREW
113	BUSHING	142	CIRCLIP	201	PUSH-IN PINION
115	TAPERED ROLLER BEARING	143	CIRCLIP	202	COVER
116	TAPERED ROLLER BEARING	144	CIRCLIP	203	ALLEN SCREW
117	DEEP GROOVE BALL BEARING / TAPERED ROLLER BEARING	145	CIRCLIP	204	JOINT
118	DEEP GROOVE BALL BEARING / TAPERED ROLLER BEARING	146	CIRCLIP	205	PIN
119	DEEP GROOVE BALL BEARING	150	SHIM	208	FILLER PLUG
120	TAPERED ROLLER BEARING	151	SHIM	209	FILLER PLUG
121	TAPERED ROLLER BEARING	152	SHIM		
124	RING	153	SHIM		

Worm gear



POS.	DESCRIPTION	POS.	DESCRIPTION
1	FLANGE BOX	12S	OIL SEAL
2	OUTPUT FLANGE	15S	CYLINDER SCREW
4	BLIND COVER	16S	CYLINDER SCREW
7	ENDLESS SCREW	17S	CYLINDER SCREW
8	CROW-OUTPUT SHAFT UNIT		
9	MOTOR FLANGE	18S	CYLINDER SCREW
10		19S	CYLINDER SCREW
1S	BEARING	20S	CYLINDER SCREW
3S	BEARING	24S	ELASTIC RIG
4S	BEARING		
5S	BEARING		
7S	BEARING		
8S	OIL SEAL		
11S	OIL SEAL		

Appendix



Tightening torque for screws

- ✓ It is the torque necessary to tighten one screw and it is defined by the screw material, its diameter and used quality.
- ✓ Tightening torque for the screws delivered by **FluidMix** are:

Carbon Steel screws		S.Steel screws	
Screw diameter mm	Tightening torque Nm	Screw diameter mm	Tightening torque Nm
1.6	0.12	1.6	0.45
2	0.25	2	0.55
2.5	0.53	2.5	0.80
3	0.91	3	1.85
4	2.09	4	4.1
5	4.14	5	8.0
6	7.1	6	13.9
8	17.4	8	33.9
10	34	10	69
12	59	12	117
14	95	14	188
16	148	16	291
18	205	18	411
20	291	20	586
22	400	22	
24	500	24	
27	741	27	
30	1005	30	
33	1366	33	

Deflectors

- ✓ In case of centred placing of vertical agitators in cylindrical tanks it is recommended to place three deflectors at 120° with a height equivalent to the 75% of the hoop height and the rest of dimensions according to the enclosed table.
- ✓ In case of tanks with dish bottom the deflector must go, at most, till the tangent line.



Tank diameter	Deflector width	Wall separation
500	40	5
600	50	10
800	60	10
1000	80	10
1200	100	20
1600	120	20
2000	150	30
2500	160	30
3000	180	30
3500	190	35
4000	200	40
4500	250	50
5000	300	60
6000	350	70
8000	400	80
10000	500	100
12000	600	120

Declaration of conformity

Declaración CE de acuerdo con la Directiva 2006/42/CE
 Declaration of conformity 2006/42/EC
 Konformitätserklärung 2006/42/EG

Tineo, 17
 28031 Madrid (Spain)
 Tel: + 34 91 170.19.24
 Fax: +34 91 494.25.26
tec@fluidmix.es ■ www.fluidmix.es

Declaramos bajo nuestra exclusiva responsabilidad que las siguientes cuasi máquinas:

Declare under our sole responsibility that the following partly completed machinery:

Erklärt eigenverantwortlich, daß die Produkte:

<i>Electroagitadores mecánicos</i>	VHS3, VHD3, VPP3, VPH3, VTS4, VTG,
Mechanical Electroagitators	VTR, HPS3, VPT, VPS, VFR, VFV, VFT
<i>Mechanische Elektrorührwerke</i>	

Están conformes con la **Directiva 2006/42/CE** aunque se prohíbe la puesta en servicio antes de que la máquina a la que será incorporada no haya sido declarada conforme a las disposiciones de la Directiva.

Are in compliance with **2006/42/EC Machines Directive** though the starting is prohibited before the machine to which it will be incorporated is in agreement with the Directive dispositions.

Auf die sich diese Erklärung bezieht, den folgenden und/oder anderen Normativen Dokumenten entsprechen wie definiert in **Maschinenrichtlinie 2006/42 EG**, obwohl die Inbetriebnahme des Geräts verboten ist bis die Maschine wo es angebant wird gemäsig zugelassen ist.



Ángel Ruiz
 Production Manager
 FluidMix, S.L.
 Madrid, 11.05.2012

ATEX Certificate

Declaration of conformity 94/9/CE

The company: FLUIDMIX S.L.
 Address : Tineo, 17
 28031 Madrid (Spain)
 C.I.F.: B-86279650

Declare under our sole responsibility that :

Product: Mixer
 Manufacturer: FLUIDMIX
 Model/s: VHS3, VHD3, VPP3, VPH3, VTS4, VTG, VTR, VTRR, HPS3, VPT, VPS, VFR, VFV, VFT



II 2G IIB c T4,
 -20°C < Ta < 40°C
 LOM 14ATEX0073

comply with the dispositions of European Directive and UNE Standards below indicated and the Essential Health and Safety Requirements:

Directive: Directive 94/9/EC relating to equipment and protective systems for use in potentially explosive atmospheres	UNE Standard: UNE- EN 13463-1 ; UNE-EN 13463-5
--	--

Responsibilities on elements or additional components, installed by the customer, as well as by the use of the product outside its operating limits or unsuitable applications are excluded.

For product assembly in any line, as well as for its maintenance follow the indications in the instruction manual.

Ángel Ruiz
 Technical Manager
 FluidMix, S.L.
 Madrid, 1.10.2014

ISO 9001

CERTIFICADO



OCA Instituto de Certificación, S.L.U.

Certifica que el Sistema de Gestión de la Calidad de la organización

FLUIDMIX, S.L.

C/ Tineo, 17- bajo 28031 MADRID

aplicable a:

**DISEÑO, FABRICACIÓN, COMERCIALIZACIÓN,
ASISTENCIA TÉCNICA DE EQUIPOS DE AGITACIÓN
Y SISTEMAS DE DOSIFICACIÓN**

conforme con la norma:

INSTITUTO DE CERTIFICACIÓN
UNE-EN ISO 9001:2008

Certificado nº **5200/12/0873**

Fecha certificado inicial: 16 de agosto de 2012

Fecha de emisión: 16 de agosto de 2012

Fecha de caducidad: 16 de agosto de 2015

El Consejero Delegado



Josep Fajula Chopo



Este certificado no tiene validez sin su contrato.

Cualquier aclaración adicional relativa tanto al alcance de este certificado como a la aplicabilidad de los requisitos de la norma se puede obtener consultando a la organización.

Avda. de les Garrigues, 46 - Parc Empresarial El Mas Blau II - 08820 El Prat de Llobregat (Barcelona)



Tineo 17
28031 Madrid
Tel.: + 34 (9)1 170 19 24
Fax.: +34 (9)1 494 25 56
fluidmix@fluidmix.es
www.fluidmix.es

